

ULTIMA 5

The Re-imagined Workforce
Data Collection Terminal



ADMIN USER GUIDE

ULTIMA2 Series
Time & Attendance Terminal

ZKTeco

ZKtechnology.com

INTRODUCTION

This is an interactive PDF document

Simply click or touch (*on touch screen*) to navigate.



Cover page



Intro page (This page)



Admin UI menu




Ultima modules,
plugs & indicators



FCC Compliance Statements


Other Resources



Biometric Privacy Concerns




Fingerprint Enrollment



Data Sheet



ULTIMA Base & Modules





Authenticate to Access



User Manager

Search a User

Enroll Fingerprint

Delete Fingerprint

Enroll Palm ID

Delete Palm ID

Enroll Badge

Delete Badge

Password

User Privilege

Verify Mode

Enroll Face ID

Delete Face ID



Tracking Code

Position



Device Setup

Badge Setup

- Wiegand Setup

- Smart Card Setup

- Barcode Setup

- Magnetic Setup

Fingerprint Setup

Facial Detection Setup

Palm Detection Setup

Thermal Module Setup

Bell Schedule

Access Control Setup

Camera Setup

Voice Commands Setup



General Settings

Display & Brightness

Sound

Date & Time



Device Info

About Device

System

Communication

Storage



Preferences

Look and Feel

Internationalization

Quick Menu

Clock Running Code

Accessibility



Admin UI



Communication

Ethernet

WiFi

Web Server

Network Diagnostics



Attendance Setup

Function Menu

Attendance Rule

Verification Rule



Data Manager

Attendance Data

Export Data

Clean Data

User Enrollment



Maintenance

Upgrade from USB

Upgrade from Server

Clock Back Up

Clock Recovery

Clock Reset

Auto Clean-up

Manual Clean-up



Technical Support

Support Contact

Troubleshooting

Initial Configurations



Provision

Update



Diagnostic

Test Barcode

Test Control Relay

Test Display & Touch

Test Biometric Sensor

Test Keypad

Test Clock Health

Test MagStrip

Test Voice

Test Wiegand

Test LED

Test Proximity

Test Camera

Test Ethernet


Test Wi-Fi and Thermal & Face




User Manager




Search a User



Select the **User Manager** icon




Select the **Search field**




Start to enter users **name** or **user ID**.

It is a dynamic string search field, which will show you results as you type




Select the **User Manager** icon




Select a **name**

Select the **Edit** button




Select **Enroll**




After reading the instruction.

Select **Continue**



Select any **available** fingerprint to be scanned.




Scanning process takes 3 steps

Step 1

For instance:


Select number 7 (index finger).

Place your index finger on to scanner bed firmly.



Step 2


Repeat the process



Step 3


Repeat the process. If successful Select **Save and Exit**

If scanning quality is inadequate it will fail. So you need to start to scanning process again



On the fingerprint field shows number of fingerprint has been recorded.


Select **Save**




After adding the fingerprint, the pop up will display as "Employee information saved successfully".



User Manager




Select the **User Manager** icon




Select a **name**.


Select the **Edit** button.




Select **Delete** button.




Select **YES** to confirm or **NO** to cancel



After delete the fingerprint, the pop up will display as "Deleted".




Select **Save** button.




After deleting the fingerprint, the pop up will display as "Employee information saved successfully".



User Manager




Select the **User Manager** icon




Select a **Name**

Select the **Edit** button



Select the **Enroll palm** button



Show your plan to the camera like shown in screen




Select **Save** button

ID	Name	Privilege
21669	aadil	Employee
21221	Abby Brennan	Employee
21577	Akshay BV	Employee
21257	Allison Hunter	Employee
21201	Amit Patel	Employee
21255	Anders Wahls	Employee
21296	Andrea Hillis	Employee
21220	Anish Majoo	Employee


"Employee After adding the palm, the pop up will display as information saved successfully".



User Manager




Select the **User Manager** icon




Select a **name**

Select **Edit**




Select the **Delete palm** button




Select **YES** to confirm or **NO** to cancel




User Manager




After delete the Palm ID, the pop up will display as "Deleted".



Select **Save** button.




After deleting the Palm ID, the pop up will display as "Employee information saved successfully".




Ideally, all the badge number updates are done in Workday, then the DCS will load it and update the latest badge number on time clock accordingly.

The option to update it in DCS or Time clock is provided as an alternative way to help the badge user, however, please keep in mind that Workday data always have the highest priority. As an example, if you have a Workday ID updated with Badge number 1111, while you already have a badge number registered in DCS or time clock as 2222, once the Badge number A is loaded automatically from Workday, your badge number will be overridden as 1111.




Select the **User Manager** icon



Select a **Name**


Select the **Edit** button




Select **Scan**




User Manager




Badge enrollment screen will display.
It is ready to scan your badge. Swipe to scan your badge.



Your badge is scanned and card number is assigned.
Select Save




The password has been updated




As an alternative, you may enter the badge number manually
Select the badge number filed and enter the badge number.
Select Save



User Manager




Select the **User Manager** icon




Select a **name**.


Select **Edit**




Select **Delete**




Select **YES** to confirm or **NO** to cancel



After deleting the badge, the pop up will display as "Deleted"




Select **Save**




After deleting the badge successfully, the pop up will display as "Employee information saved successfully".



User Manager




Select the **User Manager** icon




Select a **name**.

Select **Edit**




Select **Show**




Select verify type field, for instance **PIN & Fingerprint**




User Manager



Enter new password and select **Enter** button




Select **Edit**




The password has been updated



User Manager




Select the **User Manager** icon




Select a **name**.

Select **Edit**



Select the **Verify mode** dropdown menu.



Select privilege type field, for instance **Admin**

Admin: All the "Menu" Access.

Enrollee: Accessible to Enrolled-User Manager, Device Info and Communication Menu's.

Employee: Access to "Attendance Function Key" only.



User Manager

Edit User

User ID: 21220
 Name: Anish Majoo
 Privilege: Admin
 Badge: 1
 Alt Badge:
 Password: ...
 Fingerprint: 1
 Palm: -
 Verifv Mode: PIN

Buttons: SETUP, SCAN, DELETE, SHOW, DELETE, ENROLL, DELETE, ENROLL FACE, DELETE FACE, SAVE, CANCEL

Verify mode has been changed.

Select **Save**

User Manager

Search ID,Name

ID	Name	Privilege
21669	aadil	Employee
43705	Afeerah Malik	Employee
21257	Allison Hunter	Employee
21255	Anders Wahlström	Employee
21296	Andrea Hillis	Employee
21220	Anish Majoo	Admin
21263	Annika Nilsson	Employee
21249	Arjit Mitra	Employee


User Profile: Anish Majoo
 User ID: 21220
 Privilege: Admin
 Badge: 6463818
 Alt Badge:
 Password: ...
 Fingerprint: 1

Buttons: EDIT, DELETE


Changing user privilege is complete



User Manager




Select the **User Manager** icon




Select a **name**.

Select **Edit**



Select the **Verify mode** dropdown menu.




Select verify type field, for instance **PIN & Fingerprint**

VERIFY TYPE COMBINATIONS


- 1. PIN
- 2. Badge
- 3. Fingerprint
- 4. Face
- 5. Palm
- 6. PIN & Password
- 7. Badge & Password
- 8. PIN & Fingerprint
- 9. Fingerprint & Password
- 10. Badge & Fingerprint
- 11. PIN/Badge
- 12. PIN & Password/Badge
- 13. Face/PIN & Password/Badge/Finger
- 14. PIN & Password/Badge/Finger
- 15. PIN & Finger/Badge & Finger
- 16. Badge & Password & Finger
- 17. Finger/PIN & Password
- 18. Finger/Badge
- 19. Face / Badge
- 20. Face & Badge
- 21. Face & PIN
- 22. Face & Badge/Face & PIN
- 23. Face/Badge
- 24. Face /Finger
- 25. PIN/Finger/Badge
- 26. Face /PIN
- 27. Face & PIN




User Manager



Verify mode has been changed
Select Save




After verify mode is added, the pop up will display as
"Employee information saved successfully".




Changing user verify mode is complete



User Manager




Select the **User Manager** icon




Select a **name**.

Select **Edit**



Select **Enroll Face**



Select **Start** and put face inside the black box



Edit User


User ID	21220
Name	Anish Majoo
Privilege	Employee
Badge	2
Alt Badge	
Password	...
Fingerprint	1
Palm	-
Verifv Mode	Pin & Password & Finger

Buttons: SETUP, SCAN, DELETE, SHOW, ENROLL, ENROLL FACE, DELETE FACE, CANCEL, SAVE


Select the **User Manager** icon



User Manager




Select the **User Manager** icon




Select a **name**.


Select **Edit**




Select **Delete Face ID**




Select **YES** to confirm or **NO** to cancel



After Face is deleted successfully, the pop up will display as "Deleted".



Select **Save**




After face is deleted, the pop up will display as "Employee information saved successfully".




Tracking Code



Position



Select the **Tracking Code** icon



Job and labor codes assigned to employees.

(This is just a reference page)


Note: If applicable to customer




Device Setup




Badge Setup
 Wiegand Setup
 Smart Card Setup
 Barcode Setup




Select the **Device Setup** icon



Select the **Wiegand Setup** tab



Select the **Smart Card Setup** tab




Select the **Barcode Card Setup** tab




Device Setup



- Badge Setup
- Magnetic Setup
- Fingerprint Setup**
- Facial Detection Setup
- Palm Detection Setup




Select the **Magnetic Card Setup** tab.




Select the **Fingerprint Setup** tab

Note: Threshold should not be lowered unless a ZKTeco representative authorizes to do so.




Select the **Facial Detection Setup** tab



Select the **Palm Detection Setup** tab




Device Setup



Select the **Thermal Module Setup** tab

Note: Threshold should not be lowered unless a ZKTeco representative authorizes to do so.




Select the **Bell Schedule** tab

Select the existing bell schedule and **Edit** or select **New**




Select the Event Label field and Input a name for the schedule name. **For instance:** Morning Shift, Lunch, Break etc.




Input the time by selecting the hours and then using the keypad repeat for the minutes and finally select AM/PM




Device Setup




Select the days this schedule should reoccur



Select from the **drop down** if Internal/External bell. Internal will set off the clock speaker, External will require a Relay Board and connection to a 12v Bell or Siren



Select from the drop down what internal sound (Ring-Horn-Siren)




Select the Volume level - Duration(seconds) and Repeat Times for the settings of the Internal bell
If External settings are the same except Volume cannot be control for an external speaker




Device Setup




- Access Control Setup
- Camera Setup
- Voice Command Setup



Select the **Access Control Setup** tab
Select the Event Label field and Input a name for the schedule name. **For instance:** Morning Shift, Lunch, Break etc.



Select the **Camera Setup** tab




Select the **Voice Commands Setup** tab




General Settings




- Display & Brightness
- Sound
- Date & Time




Select the **General Settings** icon



Adjust the brightness of the screen. Adjust the amount of time before the screen goes back to the home screen. Show Notification Bar if you want messages to appear on screen



Adjust the volume that the buttons/and responses will ring



Date and Time settings. Adjust the clock, Time zone and format in which it is displayed.



Device Info



About Device
System
Communication

System Admin Menu

HOME

User Manager Tracking Code Device Setup General Settings **Device Info**

Preferences Communication Attendance Setup Data Manager Maintenance

Quick Access Network Diagnostics Display & Brightness Wifi

Select the **Device Info** icon

Device Info

HOME ADMIN

About Device

Device Name	SUDARSHAN DEVICE
OS Version	10
OS Build Number	QP1A.190711.020 mp1k61v164bspP6 release-keys
OS Build Date	01/31/2023
Serial Number	8015230940002
Device ID	unknown
Device Model	Ultima
Manufacturer	ZKTeco™
APP version	50.1.4

CLOSE

Select **About Device** to view Device Name, Device Serial Number and APP Version installed on Time-clocks

Device Info

HOME ADMIN

About Device

System

Communication

Storage

CPU Model	MT6762V/CB
CPU Frequency	2001000 Hz
Memory	1.9 Gb
Used Memory	952.2 Mb
Free Memory	996.37 Mb
Device Last Boot Time	00:15 , 09/12/2023
Device Alive Time	0 Days 0 Hours 49 Minutes
Last App Upgrade Time	05:54 , 08/28/2023

CLOSE

Select **System** to view CPU Model, CPU Frequency, Memory etc. Information

Device Info

HOME ADMIN

About Device

System

Communication

Storage

Host Name	
Ethernet Mac	00:17:61:21:0A:89
Ethernet IP	10.10.20.194
Ethernet Mask	255.255.254.0
Ethernet Gateway	10.10.20.1
WiFi Mac	00:08:22:AC:99:FB
WiFi IP	0.0.0.0
WiFi Mask	0.0.0.0
WiFi Gateway	0.0.0.0

CLOSE

Select **Communication** to view Ethernet Mac, IP and Wi-Fi Settings



Device Info

HOME ADMIN

Device Info

- About Device
- System
- Communication
- Storage**

Used Flash Storage	646.03 MB
Free Flash Storage	8930.28 MB
Total Flash Storage	9576.31 MB
User Count	23
Fingerprint Count	7
Facial Data Count	5
Attendance Log	0

CLOSE


Select **Storage** to view information about internal storage




Preferences



Look and Feel
Internationalization
Quick Menu




Select the **Preferences** icon



Select **Look and Feel** to modify;


- 1- Home screen scroll direction Horizontal or Vertical
- 2- Prompt voice female/male



Select **Internationalization** to include language(s) on home screen by checking

Languages on home represented by language abbreviations;

- EN English
 DA Dansk
 ES Española
 VI Tiếng Việt
 PT Português
 ZH 汉语
 FR Français



Select **Quick Menu** and **Select** a function from the drop downs. Selected function will be placed on admin home screen






Preferences




Clock Running Mode

Accessibility



Select the **Clock Running Mode** to choose


1. Production (is used while clock is in Normal Service)
2. Demo (will not send punches to DCS) *therefore onto workday*
3. Debug Mode (is for F/D)




Select the **Accessibility** to choose




Communication




Select the **Communication** icon



Select **Ethernet** to switch it ON




If you set DHCP = ON, then it will automatically grab IP Address from the network




If you set DHCP = OFF, then you need to enter IP Address, Subnet Mask, Gateway, DNS Server 1 and DNS Server 2.




Communication




Select the **WiFi** tab and turn WiFi switch ON



Select a network under “**Choose A Network**”



Enter Password for the selected network and Select “**Enter**” button.




Select **Join** button




Communication




WiFi
Web Server
Network Diagnostics



Connected Network will be displayed under WiFi Switch
To view details select double arrow button.




Network details



Enter correct URL for Server, also Heartbeat Interval =15 and Time Sync Interval =300


Note: Customer's Organization will have custom URL pointing to their individual tenet..




Select the **Network Diagnostic**



Attendance Setup




Select the **Attendance** icon



Select the **Function Menu** tab


Note: This should be configured from DCS Tenant



Select the **Attendance Rule** tab

Note: This will be configured prior by a ZKTeco representative and should only be for reference if a clock needs to be reconfigured.

Enable Fast Punch, Accept Consecutive Locked Punches, Enable Shift Lockout, Accept Scheduled Locked Punch, Shift Start Grace Period (Minutes) Shift End Grace Period (Minutes)




Enable Global Lockout Override, Override Start Date/Time Override End Date/Time, Enable Meal/Break Lockout, Accept Meal/Break locked punches, Meal lockout with attestation, Meal/Break Lockout Periodic (minutes).




Attendance Setup




Attendance Rule
Verification Rules



General Attestation, Accept Attestation Rejected Punch, Show Attestation Only Once Per Day, Accept Mask Failure Punches, Accept Thermal Failure Punches, Record Temperature, Enable Visitor Attestation Module



Visitor Attestation Profile, Enable Visitor Photo Capture




Select the **Verification Rules** tab
Enable 1:1 verification mode and enable clock level verification




Data Manager




Attendance Data
Export Data
Clean Data




Select the **Data Manager** icon




Select the **Attendance Data** tab
Look up Attendance logs directly on the clock.



Select the **Export Data** tab
Attendance logs to a USB drive



Select the **Export Data** tab
Select the item to be deleted
Select "start to delete" button.



Select the **User Enrollment Mode** tab

Turns offline enrollment


Note: Not recommended unless ZK representative advises




Maintenance




- Upgrade from USB
- Upgrade from Server
- Clock Back Up




Select the **Maintenance** icon



Select the **Upgrade from USB** tab.



Select the **Upgrade from Server** tab.



Select the **Clock Back Up** tab



Maintenance




Clock Recovery


Clock Reset

Auto Clean-up


Manual Clean-up



Select the **Clock Recovery** tab




Select the **Clock Rest** tab.



Select the **Auto Clean-up** tab.

Enable auto clean up and from dropdown menu and choose 1 Week, 2 Weeks, 3 Months data block.

Select **Save**



Select the **Manual Clean-up** tab.

Select a table to clean from dropdown menu and choose 1 Week, 2 Weeks, 3 Months data block.

Select Clean-Up


Note: All Upgrades will be sent by ZKTeco representative and should never be done without ZKTeco suggestion/supervision




Support Desk



- Support Contact
- Troubleshooting
- Initial Configurations




Select the **Support Desk** icon




Select the **Support Contact** tab.

These are methods on how to contact ZKTeco. Please use the ticketing system first.



Select the **Troubleshooting** tab.




Select the **Initial Configurations** tab


Note: All changes will be sent by a ZKTeco representative and should never be done without ZKTeco suggestion/supervision.



Provision



Select the **Support Desk** icon



Provision Confirmation prompt


Pulls all settings from DCS manually. No need to do this as settings are pushed from DCS frequently.




Diagnostic




Test Barcode
Test Control Relay
Test Display & Touch




Select the **Diagnostic** icon



Select the **Test Barcode** tab.



Select the **Test Control Relay** tab.



Select the **Test Display & Touch** tab



Diagnostic




Test Biometric Sensor


Test Keypad

Test Clock Health


Test MagStrip




Select the **Test Biometric Sensor** icon



Select the **Test Keypad** tab.



Select the **clock Health** tab.




Select the **Test Magnetic Stripe** tab




Diagnostic




Test Voice
Test Wiegand
Test LED
Test Proximity




Select the **Test Voice** tab



Select the **Test Wiegand** tab.



Select the **Test LED** tab.




Select the **Test Proximity** tab




Diagnostic




Test Camera
Test Ethernet
Test Wifi
Test Thermal & Face



Select the **Test Camera** tab




Select the **Test Ethernet** tab.



Select the **Test WiFi** tab.

Note: These are all tools to be used in conjunction with ZK tech support.



Select the **Test Thermal & Face** tab.



FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and, used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Declaration for EU Compliance :

5150-5350MHz is restricted in indoor used within European Union countries (AT/BE/BG/CZ/DK/EE/FR/ DE/ SE/IE/IT/ EL/ES/CY/LV/HR/LT/LU/HU/MT/NL/FL/PT/RO/SI/SK/UK)

Frequency Bands	Maximum Output Power
125KHz:	-2.75dBuA/m@10m
13.56M Hz :	-13.85dBuA/m@10m
2.4GHz BLE EIRP:	-3.11dBm
2.4GHz WiFi EIRP:	7.99dBm
5GHz WiFi EIRP:	1.13dBm
5.8GHz WiFi EIRP:	2.43dBm



Cover page



Intro page (This page)




Admin UI menu



Ultima modules, plugs & indicators

Resources



Biometric Privacy Concerns



Fingerprint Enrollment



Data Sheet



ZKTechnology.com

© Copyright 2021. ZKTeco Inc. ZKTeco Logo is a registered trademark of ZKTeco or a related company. All other product and company names mentioned are used for identification purposes only and may be the trademarks of their respective owners. All specifications are subject to change without notice. All rights reserved.