

uFACE800



USER MANUAL



CONTENT

1	USER MANAGEMENT	5
1.1	New User	6
1.2	All Users	13
1.3	Single Line	14
2	USER ROLE	16
3	COMMUNICATION	18
3.1	Ethernet	19
3.2	Serial Communication	19
3.3	PC Connection	20
3.4	Wireless Network	21
3.5	Cloud Server Settings	22
3.6	Wiegand Setup	24
4	SYSTEM	26
4.1	Date Time	27
4.2	Attendance	27
4.3	Face	30
4.3	Fingerprint	31
4.4	Reset	33
4.5	USB Upgrade	33
5	PERSONALIZE	34
5.1	User Interface	35
5.2	Voice	38
5.3	Bell Schedules	39
5.4	Punch State Options	43
5.5	Shortcut Key Mapping	44
5.6	Manual Add Log	49

CONTENT

6	DATA MANAGEMENT	51
6.1	Delete Data	52
6.2	Backup Data	53
6.3	Restore Data	54
7	ACCESS CONTROL	56
7.1	Time Schedule	57
7.2	Access Group	57
8	USB MANAGER	61
8.1	Download	62
8.2	Upload	63
8.3	Download Options	63
9	ATTENDANCE SEARCH	65
10	SHORT MESSAGE	68
10.1	New Message	69
10.2	Public Messages	71
10.3	Personal messages	71
10.4	Draft Messages	71
10.5	Message Options	72
11	WORK CODE	73
11.1	New Work Code	74
11.2	ALL WORK CODES	75
11.3	SET WORK CODE	75

CONTENT


12	JOB CODE	77
12.1	New Job Code	78
12.2	All Job Codes	79
12.2	All Job Codes	82
12.3	Job Code Options	85
12.4	Job Group Option Menu Operation	87
13	TIP CODE	90
13.1	Tip code settings	91
13.2	Tip code	92
14	AUTOTEST	96
14.1	All Test	97
14.2	Test LCD	97
14.3	Test Voice	99
14.4	Test Keyboard	99
14.5	Test Fingerprint Sensor	99
14.6	Test FACE	99
14.7	xs Test Clock RTC	100
15	SYSTEM INFORMATION	101
15.1	Device Capacity	102
15.2	Device Info	102
15.3	Firmware Info	103



USER MANAGEMENT



Select **User Management**.



1.1 NEW USER

Select **New User**.

New User

User ID	1
Name	
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	0
Badge Number	

Select **User ID**.

User ID

Please input

1

Confirm (OK) Cancel (ESC)

Enter the **User ID** by using the keypad and press **OK**.

New User

User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	0
Badge Number	
Password	

Select **User Role**.

User Role

- Normal User
- Registrar
- Super Admin

Click on **Registrar**.

New User	
User ID	2
Name	
User Role	Registrar
Verification Mode	Password/Badge
Badge Number	
Password	

A user with "Registrar" is able to "Add", "Delete" and "Edit" standard users to the device.

He is also able to view "Standard Attendance Data" for existing users on the clock.

User Role
<input type="radio"/> Normal User
<input checked="" type="radio"/> Super Admin

Select **Super Admin**.

The super administration has rights to all the menu functions.

New User	
User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	0
Badge Number	
Password	

Select **Verification Mode**

Verification mode is basically used to verify the user.

Verification Mode
<input checked="" type="radio"/> Apply Group Mode
<input type="radio"/> Password/Fingerprint/Badge
<input type="radio"/> Fingerprint only
<input type="radio"/> User ID only
<input type="radio"/> Password


Select **Apply Group Mode**. By pressing the apply group mode the user can verify himself with all the options that are available in verification mode.

Verification Mode
<input checked="" type="radio"/> Apply Group Mode
<input type="radio"/> Password/Fingerprint/Badge
<input type="radio"/> Fingerprint only
<input type="radio"/> User ID only
<input type="radio"/> Password
<input type="radio"/> Badge only


By clicking the option above the user can verify himself either with his/her **Fingerprint/Password or Badge**.

Verification Mode
<input checked="" type="radio"/> Apply Group Mode
<input type="radio"/> Password/Fingerprint/Badge
<input type="radio"/> Fingerprint only
<input type="radio"/> User ID only
<input type="radio"/> Password
<input type="radio"/> Badge only

Select **Apply Group Mode**.




When you select the option from above, the user needs all three things to verify himself or it won't verify.



When you select the options above, the user needs his/her fingerprint and either badge or user id to verify himself.

When there is / sign it means you can either use one option from 2 to verify.




To enroll the fingerprint for the new user select **fingerprint**.



Place your finger on the fingerprint sensor properly.



Place the same finger on the fingerprint sensor for the second time.




After that, you can again place the same finger on the fingerprint sensor.

USER MANAGEMENT




Enrollment succeeds. If the enrollment fails, the system will display a prompt message and return to the [Enroll Fingerprint] interface. In this case, you need to repeat the operations of step 2




After the fingerprint is enrolled successfully the fingerprint will be shown as 1 as above which means one fingerprint is enrolled.




Select "Face".



After you select face, place your face in the green box until the face gets registered for that user.




After the face is recognized for that user it will show as 1 face has been registered as above.



Select **Badge Number**.

USER MANAGEMENT



When you select the badge number it will tell you to swipe the badge/rfid card to enroll.

New User	
User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	4261414
Password	

When you swipe the badge number the badge number will be displayed as above.

Here I swiped badge number 4261414 and that number is enrolled for that user.

New User	
User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	
Password	

Select **Password**.

Password	
Please input	
<input type="text"/>	
Confirm (OK)	Cancel (ESC)

Here you can input the password by using the keypad to enroll.

New User	
User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	4261414
Password	*****

Once you entered the password the above image will be displayed for that user with his/her fingerprint the badge number and password that needs him/her to enter.

New User	
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	
Password	
Lockout Override	Disable

Select **Lockout Override**.




Select lockout override as **Disable**.




A user punches in off the activate schedules, the device will notify the user by "Error! Invalid time period Failed to verify."




Select lockout override as **Enable**.




When you enable this function the above image will be displayed.




A user punches in off the activate schedules, the device will notify the user by "Successfully Verified." as shown below




Select **Access Control Role**.




Select **Access Group**.




You can change the number for that group in the input section above using the keypad.




Select **Verification mode**.



In verification mode, you can select apply group mode which will select all the methods of verification as shown above.



Select **Duress Fingerprint**.



Place your finger as shown above to select your duress fingerprint.

Access Control	
Access Group	1
Verification Mode	Apply Group Mode
Duress Fingerprint	Undefined
Apply Group Time Period	<input checked="" type="checkbox"/> ON

Press to select **Apply Group Time Period**, to select whether the users use his/her group's default time zone.

Access Control	
Access Group	1
Verification Mode	Apply Group Mode
Duress Fingerprint	Undefined
Apply Group Time Period	<input type="checkbox"/> OFF
Time Period 1	1
Time Period 2	0

When **OFF** is selected, select **Time Period 1**.

Access Control	
Access Group	1
Verification Mode	Apply Group Mode
Duress Fingerprint	Undefined
Apply Group Time Period	<input type="checkbox"/> OFF
Time Period 1	1
Time Period 2	0




Similarly, you can choose time period 2..

New User	
Fingerprint	0
Badge Number	
Password	
Lockout Override	Disable
Access Control Role	
Duplicate Punch Period(s)	0

Select duplicate punch period.


Duplicate Punch Period(s)	
<input checked="" type="radio"/> Disabled	
<input type="radio"/> 10	
<input type="radio"/> 20	
<input type="radio"/> 30	
<input type="radio"/> 40	
<input type="radio"/> User Defined	

Here you can select **Disabled** or select the punch period you want.

User Mgt.	
 New User	
 All Users	
 Display Style	

1.2 ALL USERS


Select **All users**.



Click to select "All User".




Here you can edit the user information by selecting **Edit**.



The User ID cannot be modified, and the other operations are similar to those performed to add a user.



If you want to delete the user select **Delete** as shown above and the user will get deleted.



1.3 SINGLE LINE

Click to select display style you wish to apply.



Single Line

All Users		
1	Joe	🔍 📄 🔑
2	David	🔍
3	Mark	🔍 🔑
4	Jack	🔍
5	June	🔍 🔑
<input type="text"/>		

Multiple line

All Users		
1	Joe	🔍 📄 🔑
2	David	🔍
3	Mark	🔍 🔑
4	Jack	🔍
5	June	🔍 🔑
<input type="text"/>		

Mixed Line



USER ROLE



Select **User Role**.



Click on **Registrar**.

He is also able to view "Standard Attendance Data" for existing users on the clock



Here you can **Enable the defined Role** for user by turning it ON.




Select **Define User Role**.




Here you can select the rights you want to assign.



COMMUNICATION




Select "COMM".




3.1 ETHERNET

Select **Ethernet**.



IP Address: IP is 192.168.1.201 by default. You can modify it if it is necessary. But it cannot be the same with that of PC.




3.2 SERIAL COMMUNICATION

Select **Serial Comm**.



Select "Serial Port".



RS232: Whether or not use RS232 to communicate. Select RS232.

Serial Comm	
Serial port	no using
Baudrate	115200

Select **Serial Port** as no using if you do not want to use the port.

Serial port	
<input type="radio"/> no using	
<input checked="" type="radio"/> RS232(PC)	

Baudrate: Used for communication with PC.

Baudrate	
<input checked="" type="radio"/> 115200	
<input type="radio"/> 57600	
<input type="radio"/> 38400	
<input type="radio"/> 19200	

There are five options: 9600, 19200, 38400, 57600 and 115200. If the communication speed is high, RS232 is recommended. If the communication speed is low, RS 485 is recommended

Comm.	
Ethernet	
Serial Comm	
PC Connection	
Cloud Server Settings	
Wiegand Setup	

3.3 PC CONNECTION


Select **PC connection**.

PC Connection	
Comm Key	0
Device ID	1
Use SSH	<input type="checkbox"/> OFF


Select **Comm Key**.

Comm Key	
Please input (0 ~ 999999)	
<input type="text" value="0"/>	
Confirm (OK)	Cancel (ESC)


Enter a password, using the keypad in the input box as shown above and Click **OK**.




Select **Device ID** ..



Here you can put the number for this device by using the keypad in the input screen as shown above and press **OK**.




Here the **Use SSH** is **OFF**




When you turn **ON** the "SSH" function the device will restart automatically as shown above.

When this function is enabled you cannot "Telnet" into the clock as it will disable that function.




3.4 WIRELESS NETWORK


Click on **Wireless Network** .



When you select the wireless network option the following window will appear in which as a default **WIFI** would be **OFF**.




You can turn **ON** the wireless network and the networks available in the range would be displayed as above.




You can select any wireless network you wish to connect and you can upload the password via "USB" or by using the keypad on the clock. Once you upload the password the following network will get connected.

See NOTE below




3.5 CLOUD SERVER SETTINGS

Click on **Cloud Server Settings**.




Select **Server mode** as "PUSH" as shown above.

It refers to your push server address.



Here the "URL" MODE IS "OFF".



You can turn the "URL" mode "ON" by pressing the **M/←** button on the clock.

NOTE: The new filename for uploading Wi-Fi password or URL Webserver: updataoptions2.cfg

Inside this file you can either use: WirelessKey= [for uploading Wi-Fi password] or ICLOCKSVRURL= [for uploading webserver URL]

The clock won't accept saving those two configurations under the same filename. Our suggestion would be to save one separate file for Wi-Fi and one for URL.

Cloud Server Settings	
Server mode	PUSH
URL Mode	<input checked="" type="checkbox"/> ON
Server Address	192.168.10.206
Upload Server Address	
Enable Proxy Server	<input type="checkbox"/> OFF

Once the "URL Mode" is "ON" you can upload the server address with "USB".

See **NOTE** below

Cloud Server Setting	
Server mode	PUSH
Server Address	192.168.10.206
Server port	80
Enable Proxy Server	<input type="checkbox"/> OFF

Here the server address is the IP address of the webserver.

Server Address

Please input

192 . 168 . 10 . 206

Confirm (OK) Cancel (ESC)

Here you can change server port of the webserver by using the keypad and press **OK**.

Cloud Server Setting	
Server mode	PUSH
Server Address	192.168.10.206
Server port	80
Enable Proxy Server	<input type="checkbox"/> OFF

Select **Server port**. It is a port which is used by the webserver.

Server port

Please input (0 ~ 65535)

80

Confirm (OK) Cancel (ESC)

Here you can change server port of the webserver by using the keypad and press **OK**.

Cloud Server Setting	
Server mode	PUSH
Server Address	192.168.10.206
Server port	80
Enable Proxy Server	<input type="checkbox"/> OFF

Here you can select the proxy server to be **Enabled** or not. If it is off as above the proxy server will be disabled.

NOTE: The new filename for uploading Wi-Fi password or URL Webserver: updataoptions2.cfg

Inside this file you can either use: WirelessKey= [for uploading Wi-Fi password] or ICLOCKSVRURL= [for uploading webserver URL]

The clock won't accept saving those two configurations under the same filename. Our suggestion would be to save one separate file for Wi-Fi and one for URL.

Cloud Server Setting	
Server mode	PUSH
Server Address	192.168.10.206
Server port	80
Enable Proxy Server	<input checked="" type="checkbox"/> ON
Proxy Server IP	0.0.0.0
Proxy Server Port	0

When you enable the proxy function, set the IP address and port number of the proxy server. This option indicates whether to use a proxy IP address. You may choose to enter the proxy IP address or the server address for Internet access, whichever you like.

Comm.	
	Ethernet
	Serial Comm
	PC Connection
	Cloud Server Settings
	Wiegand Setup

3.6 WIEGAND SETUP

Click on **Wiegand Setup**.

Wiegand Setup	
Wiegand Output	
Auto Detect Card Format	

Select **Wiegand Output**

Wiegand Options	
Wiegand Format	
wiegand output bits	26
Failed ID	Disabled
Site Code	Disabled
Pulse Width(us)	100
Pulse interval(us)	1000

Here you can edit the Wiegand Output options you wish to apply.


Wiegand Setup	
Wiegand Output	
Auto Detect Card Format	

Select **Auto Detect Card Format**


(This function is available only for standard RFID and HID proximity Cards)

Card format detect automatically	
Please swipe badge...	

Here you can swipe the multiple types of cards with different Wiegand formats.




After you swipe multiple cards all the cards with different Wiegand formats will be displayed as above.



Here you can select the Wiegand format of the card you wish to choose to register.

If you select "Cancel" that Wiegand format would not be selected.




To select the particular Wiegand card format select that format and press **OK** as shown above.



SYSTEM



Select "System".




4.1 DATE TIME

Select **Date Time**.




Select items. When the setting is completed, press **OK** to save the setting and exit.




4.2 ATTENDANCE


Select **Attendance**.




If you want to display the user photo you can select **ON**




If you don't want the user photo to be displayed select **OFF** as above.




When the available space is insufficient to store the specified number of attendance records, the FFR terminal will automatically generate an alarm. (Value scope: 1-99)




You can change the value for attendance log alert from the image above.




Select **Cyclic Delete ATT Data**. It specifies the maximum number of attendance records that can be deleted at a time when the number of attendance records reaches the upper limit.



This function can be disabled; otherwise, the value ranges from 1 to 999



The screen delay specifies the time for displaying the authentication result.



The value ranges from 1s to 9s.

Attendance	
Display User Photo	<input checked="" type="checkbox"/> ON
Attendance Log Alert	99
Cyclic Delete ATT Data	Disabled
Confirm Screen Delay(s)	3
Expiration Rule	<input type="checkbox"/> OFF

You can select the expiration rule as OFF if you don't want to retain the user information or to save attendance records.

Attendance	
Display User Photo	<input checked="" type="checkbox"/> ON
Attendance Log Alert	99
Cyclic Delete ATT Data	Disabled
Confirm Screen Delay(s)	3
Expiration Rule	<input checked="" type="checkbox"/> ON
Expiration Rule Options	Keep user, No audit future punch

You can select one of the three conditions:

- Retaining user information and not saving attendance records;
- Retaining user information and saving attendance records;
- Deleting user information

Attendance	
Display User Photo	<input checked="" type="checkbox"/> ON
Attendance Log Alert	99
Cyclic Delete ATT Data	Disabled
Confirm Screen Delay(s)	3
Expiration Rule	<input type="checkbox"/> OFF
Verification Result Font Customization	<input type="checkbox"/> OFF

Click on **Verification Result Font Customization** option from above and press ON to change the Font Size.

Attendance	
Cyclic Delete ATT Data	Disabled
Confirm Screen Delay(s)	3
Expiration Rule	<input type="checkbox"/> OFF
Verification Result Font Customization	<input checked="" type="checkbox"/> ON
Verification Result Font Size	Medium
Verification Result Font Color	WHITE


Here the default font size would be set to "Medium".

Verification Result Font Size	
<input checked="" type="radio"/> Medium	
<input type="radio"/> Large	
<input type="radio"/> Maximum	


Here you can change the font size from "Medium" to "Large" or "Maximum".

Attendance	
Cyclic Delete ATT Data	Disabled
Confirm Screen Delay(s)	3
Expiration Rule	<input type="checkbox"/> OFF
Verification Result Font Customization	<input checked="" type="checkbox"/> ON
Verification Result Font Size	Medium
Verification Result Font Color	WHITE

Select "Verification Result Font Color" from above and press "OK"




Here you can change the color of the font to a different color you wish to apply.




4.3 FACE


Select **Face**.



You can change the setting of face templates from the options above.




Select "Show Attendance State" and turn "ON". Once you turn "ON" you can change the attendance state font size and color.




Select "Attendance State Font Size"




Here you can change the font size to "Medium", "Large" or "Maximum" you wish to apply.



Select **Attendance State Font Color**



You can change the font color to any color from the option above you wish to apply



4.3 FINGERPRINT


Select **Fingerprint** option and click **OK**.



Here select **1:1 match threshold** The value is similar to the ID+fingerprint verification and the enrolled template.




You can change the value from the image above. The default will be selected as 15.




Here select **1:N match threshold** The value is similar to verification and the enrolled template.




You can change the value from the image above.
The default will be set to 35



Select **FP sensor Sensitivity**. It is used to set the sensitivity of fingerprint collection.




The default value Medium is recommended. You can set the sensitivity of fingerprint collection to High when the response to finger scan lags in a dry environment. When the usage environment is humid, you can set the sensitivity of fingerprint collection to Low if the fingerprint is difficult to identify.




This parameter is used to set the retry times in the event of failure of 1:1 verification or password verification due to an absence of fingerprint enrollment or improper finger placement, so as to avoid repetitive operations.




You can change the retry times from the image above. The value ranges from 1 to 6.



Here you can select the **Fingerprint Image** to Always show. If you select this option the display of the fingerprint image on the screen will be shown.




Here you can change the fingerprint image to be shown while enrolling or to match, or never.




4.4 RESET

Select **Reset**.



When you select **Cancel** it will go back to previous menu.
If you select **OK**, it will reset the setting and restart the clock.



4.5 USB UPGRADE

Select **USB Upgrade**.



If the USB is not readable or properly inserted the image above will be displayed and you will not be able to upgrade.




If the USB is readable or properly inserted the image above will be displayed and you will be able to upgrade.



PERSONALIZE




Select **Personalize**.




5.1 USER INTERFACE


Select **User Interface**.




Select **Wallpaper**.




If you select the wallpaper the different wallpaper will be displayed as shown above and you can select any of the wallpaper you want to be displayed.




Select **Language**.




Here you can select the language you wish to display on the clock. The options are English and Español (Spanish).




To prevent hostile power-off, select whether to lock power-off or not.
 "disable": the power is off 3 seconds after pressing power-off.




"Enable": it is ineffective after pressing power-off



The device will display the main interface automatically when no operation is performed on a menu within the menu timeout time




This function can be disabled; otherwise, the value ranges from 60s to 99999s.




The advertisement picture is displayed when no operation is performed on the main interface within the waiting time.




This function can be disabled; otherwise, the value ranges from 15s to 999s




This parameter is used to set the picture cycle interval




This parameter can be either disabled or ranges from 30 s to 999s.




This parameter is used to set the picture cycle interval




This parameter can be either disabled or ranges from 30 s to 999s.




This parameter is used to specify a period after which the device is put in sleep mode if no operation within this period. You can wake up the device from sleep by pressing any key or touching the screen.




Numerical range in 30 minutes, the factory default for 30 minutes.




This is to set where and how the clock and status key are displayed on the main screen.




Here is the "Style 1". If you want this style press SET. And if you don't want this style simply press back.



Here is the "Style 2". If you want this style press SET. And if you don't want this style simply to press back.




Here is the "Style 3". If you want this style press SET. And if you don't want this style simply press back




5.2 VOICE


Select **Voice**.



Voice prompt: This parameter is used to set whether to play voice prompts during the operation of the FFR terminal. Select **ON** to enable the voice prompt, and select **OFF** to mute.




Touch prompt: - This parameter is used to set whether to generate beep sound in response to every keyboard touch. Select **ON** to enable the beep sound, and select **OFF** to mute



5.3 BELL SCHEDULES


Select **Bell Schedules**.




Click on **New bell schedule**.




Click on bell status. It is whether or not you want the bell to enable. If you turn **OFF** it will disable the bell.



If you turn **ON** it will enable the bell.




The bell rings automatically when it is the specified time.



You can change the timings for the bell to ring using the keypad and then confirm **OK**.


Here the bell is schedule at 12.24PM.




The Repeat function specifies whether to repeat the ringtone




You can select any day of the week to repeat the ringtone. And if you don't want the ringtone to be repeated set to never.



Select **Bell Type** and press **OK**.




Here you can select the bell type. If you want the ringtone to be played internally than select internal bell, for external select external bell and for both select internal and external bell.



Select **Ringtone** and press **OK**.



You can select any ringtone you want from the above options.




Select **Internal bell delay(s)** and press **OK**.


It specifies the duration for ringtone playing.




You can edit the delay of the internal bell from the image above. It ranges from 5 to 99 seconds.




Select **All bell schedules**.



Select New Bell Schedule.



Select **Edit** to edit the bell schedules



New Bell Schedule

Bell Status ☒ ON

Bell Time


Repeat Never

Bell Type Internal Bell

Ring Tone bell01.wav

Internal bell delay(s) 5

Select Item you wish to edit.




12:22

Edit

Delete

Press **Delete** to delete the bell schedule.



12:22

Edit


Delete

Are you sure to execute?

Yes

No

Select **YES** or **NO**.




Bell Schedules

New Bell Schedule

All Bell Schedules

Options


Press to select **Options**.



Options

External Bell Relay NC2

Select **External Bell Relay**.




External Bell Relay

☐ Disabled

☐ NC1


☒ NC2

Press to select, press **OK** to save and return.




5.4 PUNCH STATE OPTIONS


Press to select **Punch State Options**.




Press to select items. When the setting is completed, press **OK** to save the setting and exit.




The main interface displays the status keys that can be switched automatically, and you are also allowed to switch status keys manually. A status key you select manually will be switched according to the automatic switching plan after it disappears upon a timeout.




Punch state timeout specifies the timeout period of the status key displayed on the main interface.




You can change the punch state timeout from the image above. The timeout ranges from 5 to 99 sec.



specifies whether the status of work attendance check must be selected during authentication. Here when its off it won't be selected.




Specifies whether the status of work attendance check must be selected during authentication.
When it's on it will be selected.




5.5 SHORTCUT KEY MAPPING

Press to select **Shortcut Key Mappings**.



These are standard attendance keys for Uface.



You can select any keys you wish to use from the above menu



Select **F1** key as **Check in**.



Select **Punch State Value**.

Punch State Value

0

1 2 3

4 5 6

7 8 9

ESC 0 123 OK

Here you can change the punch state value in the input screen by using the keypad and press "OK".

F1

Punch State Value 0

Function Punch State Options

Name Check-In

Set Switch Time

Select Job Group Disable

Set Font Size Medium

Here select punch state options as **Function**.

Function

Undefined

Punch State Options

New User

All Users

Ethernet

Serial Comm

You can choose the key for F1 that you want from the options above.

F1

Punch State Value 0

Function Punch State Options

Name Check-In

Set Switch Time

Select Job Group Disable

Set Font Size Medium

Select name for F1

Name

User Defined

Check-In

Check-Out

Break-Out

Break-In

Overtime-In

You can name the key for F1 you want from the options above. Here F1 is selected as "Check in".

F1

Punch State Value 0

Function Punch State Options

Name Check-In

Set Switch Time

Select Job Group Disable

Set Font Size Medium

Similarly, you can select the Job group or font size for that key you wish to apply.

Here you can **Switch Cycle**

Select job group and press **OK**. If you disable, the job group will be disabled and it will not show on the screen.

You can select any job group you want and you can name the job group by using the keypad.

If you "Disable" the tip group the tip group will not be displayed on the screen.

To enable the tip group you can select the tip group you wish to enter in that group.

Here all the tip groups have been selected as above.

Shortcut Key Mappings	
F1	Check-In
F2	Check-Out
F3	Break-Out
F4	Break-In
F5	Tip Code
F6	Overtime-Out

Select **F2** as **Check Out**.

F2	
Punch State Value	1
Function	Punch State Options
Name	Check-Out
Set Switch Time	
Select Job Group	Disable
Select Tip Group	Disable

Select **Punch State Value**.

F3	
Punch State Value	251
Function	Tip Code
Select Tip Group	Disable

Select **F3** as "Tip code".

Here the punch state value is set to 251

For more details refer to paragraph 13.

Punch State Value	
Please input (0 ~ 254)	
<input type="text" value="251"/>	
Confirm (OK)	Cancel (ESC)

You can change the value of the punch state by changing the value in the input screen with the help of keypad.

F3	
Punch State Value	251
Function	Tip Code
Select Tip Group	Disable

Select **F3** as **Tip code**. For more details refer to No 13.

Function	
<input type="radio"/>	Firmware Info
<input type="radio"/>	Work Code
<input type="radio"/>	Public Message
<input type="radio"/>	Personal Record Search
<input type="radio"/>	Job Code
<input checked="" type="radio"/>	Tip Code

You can change the function for that key from the image above.

Here the tip group is disabled and no tip group has been selected.


You can select the tip group you want. Here all the tip groups are selected

When you select all the tip groups, the select tip group will display as "All group".

Select **F4** as **Break-In**.


Select the **Function** Break-In for F4 and the F4 key will display as Break-In on the main screen.

You can change the functions from above.




5.6 MANUAL ADD LOG

Select Manual add log and press **OK**.



Click on **User ID**



The user id is displaying as 1.



Click on **Verify mode.**



Here you can select any verification mode you want the user to get verified. The user can verify themselves either with their UserID, Fingerprint, Password or Card/Badge.



Select verify state as none. In this all the users from all states can verify themselves.
If you verify the state the user from that state can only verify themselves.

Manual Add Log	
User ID	
Verify Mode	
Verify State	None
Date	11/03/17
Time	

Select **Date**.

Date		
11/03/17		
<div><div>+</div><div>2017</div><div>-</div></div> <div>YYYY</div>	<div><div>+</div><div>11</div><div>-</div></div> <div>MM</div>	<div><div>+</div><div>03</div><div>-</div></div> <div>DD</div>
Confirm (OK)		Cancel (ESC)

You can set the date by using the keypad. Here the date is set to 11/03/2017.

Manual Add Log	
User ID	
Verify Mode	
Verify State	None
Date	11/03/17
Time	

Select **Time**.

Time			
12:43:38 PM			
<div><div>+</div><div>12</div><div>-</div></div> <div>HH</div>	<div><div>+</div><div>43</div><div>-</div></div> <div>MM</div>	<div><div>+</div><div>38</div><div>-</div></div> <div>SS</div>	<div><div>+</div><div>PM</div><div>-</div></div>
Confirm (OK)		Cancel (ESC)	


You can set the "Time" by using the keypad. Here the time is set to 12hr, 43min, 38ss.



DATA MANAGEMENT




Select **Data Manager**.




6.1 DELETE DATA


Select **Delete Data**.




It will delete the attendance records



When **Delete All** is selected, it will delete all the attendance records.




You can delete the attendance data by Time Range too.




To selete by time range you can select the time you want the data to be deleted.


It will delete the data for that specific time you selected.



Here you can delete all data by selecting delete all data and press **OK**. **CANCEL** will take you back to previous screen.




Here you can delete admin role by selecting delete admin role and press **OK**. **CANCEL** will take you back to previous screen




6.2 BACKUP DATA


Select **Backup Data**.




Select **Backup to Device** to back up the content from the device.




Select the local configuration items to be backed up to device the selected items.



You can select the content you want to backup.




Select **Backup Start** and once the backup is completed the above image will be displayed.



Select **Backup to USB Disk**, the operations are similar to those performed to Backup to Device.



If the usb is not properly inserted the above screen will be displayed. You can either change the USB or insert it properly again.




6.3 RESTORE DATA


Select **Restore Data**.




Select **Backup from Device**.



Select the local configuration items to be restored and save the selected items.




You can select the content you want to restore.



select **Start Restore** and press **OK**.

select **Yes** or **NO** Device and press **OK**.



Restore from USB Disk the operations are similar to those performed to restore from Device.




If the USB disk is not properly inserted the above screen will be displayed. You can either change the USB or insert it properly again.



ACCESS CONTROL




Select **Access Control**.




7.1 TIME SCHEDULE


Select **Time Schedule**.



Use numeric keys to search for a time period in the range from 1 to 50.
Select the item to be set.




Press / to select a time option and press ▼ / ▲ to set time. After setting a period of time, press **OK** to save the setting and exit



7.2 ACCESS GROUP

Select **Access Groups**.



Press **OK** to add **New Group**

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	<input type="checkbox"/> OFF

Press **OK**.

No.
Please input (1 ~ 99)
2
Confirm (OK)
Cancel (ESC)

Enter the No. using keypad and press **OK**.

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	<input type="checkbox"/> OFF

Select **Verification Mode**.

Verification Mode	
<input checked="" type="radio"/>	Password/Fingerprint/Badge
<input type="radio"/>	Fingerprint only
<input type="radio"/>	User ID only
<input type="radio"/>	Password
<input type="radio"/>	Badge only
<input type="radio"/>	Fingerprint/Password

Select Verification Mode, you wish to apply and save and return.

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	<input type="checkbox"/> OFF

select **Time Period 1**.

Time Period 1
Please input (0 ~ 50)
1
Confirm (OK)
Cancel (ESC)

Enter the No. using keypad.

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays <input type="checkbox"/> OFF	

Select **Include Holidays** to enable the item

Access Groups
New Group
All Groups

Select **All Groups**.

All Groups	
1	01 00 00
2	01 00 00

Select one of All Groups.

Access Groups
Edit
Delete


Select **Edit**.

Access Groups	
No.	1
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays <input type="checkbox"/> OFF	

The No. cannot be modified, and the other operations are similar to those performed to add a new group. Press left arrow on the screen to return

Access Groups
Edit
Delete

select **Delete**.




If you select **OK** it will delete all the access groups and when you select **Cancel** it will take you to previous screen without deleting any access groups.



USB MANAGER




Go to Menu and select USB Manager.




8.1 DOWNLOAD

Select **Download**.




Select the items you want to download.


Here when we select the "Attendance Data" it will import all the attendance data from the FFR terminal to USB disk




User data will import all the user information, fingerprints and facial images from the FFR terminal to a USB disk




User Portrait will import the employees' photos from the terminal to a USB disk.



Work code will save the work IDs on the device to a USB drive




The short message will be displayed by the administrator and will be imported from terminal to USB disk.



8.2 UPLOAD


Select **Upload** and press **OK**.

In Upload it will upload all the data from USB disk to terminal.




Screen saver will Upload the JPG documents with "ad_" as initial letters of document names stored in a USB disk to the terminal. After the upload, these pictures can be displayed on the initial interface of the terminal.

See page 64 for detailed instructions




8.3 DOWNLOAD OPTIONS


Select **Download Options**.




Select items from the options above. When the setting is completed, select to save the setting and exit.



This will download all the encrypted attendance data of the employee.



If the **ATT data** is **OFF**, it won't download any data as the function is disabled.



If the **ATT data** is **ON** it will download the data as the function is enabled.



Instructions for Uploading Wallpapers and Screensavers Via USB Pen Drive

PREREQUISITES: Supported File Extensions: bmp, jpg, png | Image File Size: No larger than 200 KB | Resolution Sizes: 480 x272 pixel

Wallpaper:

1. Created a folder in the root of the USB drive labeled **wallpaper**
2. Place the desired wallpapers inside this folder. Make sure to follow the supported file types and sizes.
3. The filename for each image should be followed as the image below:

Name	Size	Type
wallpaper9.jpg	38 KB	JPG File
wallpaper10.jpg	43 KB	JPG File
wallpaper11.jpg	12 KB	JPG File
wallpaper12.jpg	80 KB	JPG File
wallpaper13.jpg	43 KB	JPG File

Make sure to start from **wallpaper9.jpg** to avoid overwriting existing wallpaper images

4. Insert USB drive to device and navigate to USB Manager>Upload>Wallpaper.
5. Select the images you wish to upload or upload all the pictures at once.

Screen Saver:

1. Created a folder in the root of the USB drive labeled **advertise**
2. Place the desired screen savers inside this folder. Make sure to follow the supported file types and sizes.
3. The filename for each image should be followed as the image below:

Name	Size	Type
ad_pic9.jpg	38 KB	JPG File
ad_pic10.jpg	43 KB	JPG File
ad_pic11.jpg	12 KB	JPG File
ad_pic12.jpg	80 KB	JPG File
ad_pic13.jpg	43 KB	JPG File

Make sure to start from **ad_pic9.jpg** to avoid overwriting existing screensaver images

4. Insert USB drive to device and navigate to USB Manager>Upload>Screen Savers.
5. Select the images you wish to upload or upload all the pictures at once.




ATTENDANCE SEARCH


ATTENDANCE SEARCH



Select **Attendance Search**



Select **Attendance Record**



Enter the "User ID" of the user you wish to see the attendance record




Here you can select the time range you wish to see for the record of that user.

The different options are available as shown above.


Personal Record Search		
Date	User ID	Attendance
12-11	1	Number of Records:02 15:37 15:37

Prev : Left key Next : Right key Details : OK

The records in accordance with the conditions will be displayed as above.



Select **Attendance Photo**



A screen titled "User ID" with a numeric keypad. The keypad has buttons for digits 1-9, 0, and a "123" button. There are also buttons for "ESC", a backspace "x", and an "OK" button. Navigation arrows are present on the right side of the keypad.


Enter the "User ID" of the user you wish to see the attendance photo.



A screen titled "Time Range" with a list of options: "Today", "Yesterday", "This week", "Last week", "This month", and "Last month". Each option has a radio button next to it. A back arrow is on the top left, and a menu icon is on the top right.

Here you can select the time range you wish to see for the record of that user.

The different options are available as shown above.



A screen titled "Attendance Search" with three menu items: "Attendance Record", "Attendance Photo", and "Blacklist ATT Photo". Each item has a small icon to its left. The "Blacklist ATT Photo" item is highlighted with a green background.

Select **Blacklist ATT Photo**.


Here you can search for the pictures of the user which are blacklisted in the attendance record.



SHORT MESSAGE



Go to Menu and select **Short Message** .



10.1 NEW MESSAGE


Click on **New Message** .




Click on the "Message" option as shown above.



After you click on "Message" the above screen will appear in which you can type the message with the help of keypad you wish to send.



Click on **Start Date**.



Here you can edit the date you wish the message to be displayed.

New Message	
Message	
Start Date	02-08-18
Start Time	11:50 AM
Expired Time (m)	60
Message Type	Draft

Click on **Start Time**.

Start Time		
11:50 AM		
<div> <div>+</div> <div>11</div> <div>-</div> </div> <div>HH</div>	<div> <div>+</div> <div>50</div> <div>-</div> </div> <div>MM</div>	<div> <div>▲</div> <div>AM</div> <div>▼</div> </div>
Confirm (OK)		Cancel (ESC)

Here you can edit the "Start Time" to what time you want the message to be displayed.

New Message	
Message	
Start Date	02-08-18
Start Time	11:50 AM
Expired Time (m)	60
Message Type	Draft

Click on **Expired Time**.

Expired Time (m)	
<input type="radio"/>	Never Expire
<input type="radio"/>	30
<input checked="" type="radio"/>	60
<input type="radio"/>	90
<input type="radio"/>	120
<input type="radio"/>	User Defined

Here you can choose the time you want the message to be expired from the screen.

The "Expired Time" ranges in minutes.

New Message	
Message	
Start Date	02-08-18
Start Time	11:50 AM
Expired Time (m)	60
Message Type	Draft


Click on **Message Type**.

Message Type	
<input type="radio"/>	Public
<input type="radio"/>	Personal
<input checked="" type="radio"/>	Draft

From the menu above you can select the "Message Type" you wish to display.




Go to Menu and select **Short Message**.




10.2 PUBLIC MESSAGES

Select **Public Message**.




The message will be displayed on the screen as above.




10.3 PERSONAL MESSAGES

If you want to view any Personal Message click on **Personal Messages**




10.4 DRAFT MESSAGES

Select **Draft Messages**.




The draft messages will be displayed as above.



10.5 MESSAGE OPTIONS

Select **Message Options** .



Select "Message Show Delay" to set the delay time for the message to be seen.




Select the **Time** you want the message to be seen.
The delay time ranges in seconds.



WORK CODE



Go to menu and select **Work Code**.




11.1 NEW WORK CODE


Select **New Work Code**.




Select **ID**.




Enter the user ID using keypad for that user.



Select **Name**.




Enter the name of the work code by using the keypad.




11.2 ALL WORK CODES

Select **All work codes**.




View **All work codes**.




Select the one you want to edit or delete.

In edit you can edit the information and delete will delete the work code for that ID.




11.3 SET WORK CODE


Select **Work code options**.



When the work code required is **OFF** it will disable the required work code.




Select **ON** for workcode required.




When you turn **ON** the workcode required it will ask you to set the timeout for the input screen.

Click on input screen timeout.




Here you can change the timeout for the input screen from the image above.

The timeout is in seconds.



When you select **OFF** for the function above the work code will not be defined and will be disabled.



When you turn **ON** the work code, it will be defined and will enable that function.



JOB CODE



Select **Job code** icon.



12.1 NEW JOB CODE


Select **New Job Code**




Select Job Group ID and then assign a particular job code from the category such as **Country** as shown above.



Select **Country**. The job group id will be selected as country.



Select **Job Code ID**



Enter Job Code ID or edit Job ID to represent the job code such as NO. 1 as shown above.

Job Group ID	Country	Job Code ID	Job Code Name
		1	

Select **Job Code Name**.

Please input

[Aa]

Input the **Job Code Name** in the box above. With the help of keypad you can input the name.

Please input

USA

[Aa]

Enter the job code name **USA** as shown above

Job Group ID	Country	Job Code ID	Job Code Name
		1	USA

All input information you enter will be displayed on the screen as above. Press "ESC" button to go back to last menu and it will save all the information you entered

Main Menu

User Mgt User Role COMM System Personalize Data Mgt

Access Control USB Manager Attendance Search Short Message Work Code Job Code

12.2 ALL JOB CODE

Go to menu and select **Job Code**

Job Code

New Job Code

All Job Codes

Job Code Options

Job Group Options

Select **All JOB codes**.

Select Job Group
<input checked="" type="radio"/> Country
<input type="radio"/> State
<input type="radio"/> City
<input type="radio"/> Block
<input type="radio"/> Street
<input type="radio"/> Zip

Select **Country**

All Job Codes	
1	USA
2	UK
3	Mexico
4	Canada

There is only one job code (USA) assigned to this group Country 1

Select Job Group
<input type="radio"/> Country
<input checked="" type="radio"/> State
<input type="radio"/> City
<input type="radio"/> Block
<input type="radio"/> Street
<input type="radio"/> Zip

Select **State**

All Job Codes	
61	Greater Manchester
201	New Jersey
202	Washington
212	New York
312	Illinois
808	Hawaii

After selecting state, it will display all the job codes assigned to different states as shown above.

Select **Great Manchester** as shown above to select the particular state

Select Job Group
<input type="radio"/> Country
<input type="radio"/> State
<input checked="" type="radio"/> City
<input type="radio"/> Block
<input type="radio"/> Street
<input type="radio"/> Zip

Select **CITY**

All Job Codes	
1	Honolulu
2	Chicago
3	Manchester
26	Mexico City
201	Jersey City
973	Piscataway

After selecting CITY all the job codes will be displayed according to the city as shown above and you can select whichever is applicable to you.

Select Job Group

☒ Country

☐ State

☐ City

☒ Block

☐ Street

☐ Zip

Select **BLOCK**

All Job Codes

1	1st block
2	8th block
3	5th block
4	101 block

The different blocks will appear.

Select 1st block as shown above to select the particular block

Select Job Group

☒ Country

☐ State

☐ City

☐ Block

☒ Street

☐ Zip

Select **Street**

All Job Codes

1	Market Street
2	West Main Street
3	East Street
4	Sepulveda Blvd
5	Bernardino Road

The different Streets will appear as shown above.

Select Market street as shown above to select the particular street

Select Job Group

☒ Country

☐ State

☐ City

☐ Block

☐ Street

☒ Zip

Select **ZIP**

All Job Codes


1	08854
2	08856
3	07097
4	07101
5	91740
6	90249

The different ZIP codes will appear as shown above.

Select ZIP Code 08854 as shown above to select the job code for that zip code.



Select **Job Code**



12.2 ALL JOB CODES


Select the **All Job codes** option.



Select **Country**

All Job Codes	
1	USA
2	UK
3	Mexico
4	Canada

The job codes assigned to different countries will be displayed as shown above. Select **1 USA** for the particular job code for that country.



After selecting 1 USA click on the **Edit** function.



Click on the **Job code ID** if you want to change to the id number from 1 to a different number.

The 'Edit' screen displays a table with two rows. The first row is 'Job Code ID' with the value '1'. The second row is 'Job Code Name' with the value 'USA'. The 'Job Code Name' row is highlighted in green.

Edit	
Job Code ID	1
Job Code Name	USA

Click on **Job Code Name** to edit the name for that job code

The 'Job Code Name' screen shows a 'Please input' prompt above a text input field containing 'USA'. Below the input field is a keyboard icon labeled '[Aa]'.

Job Code Name

Please input

USA

[Aa]

Enter the **Job code Name** by using the keypad.

The 'Job Code Name' screen shows a 'Please input' prompt above a text input field containing 'America'. Below the input field is a keyboard icon labeled '[Aa]'.

Job Code Name

Please input

America

[Aa]

Change the name from "USA" to America

The 'Job Code Name' screen shows a 'Please input' prompt above a text input field containing 'America'. Below the input field are two buttons: 'Confirm (OK)' and 'Cancel (ESC)'.

Job Code Name

Please input

America

Confirm (OK) Cancel (ESC)

Click on confirm **OK** button to select America.

The 'Edit' screen displays a table with two rows. The first row is 'Job Code ID' with the value '1'. The second row is 'Job Code Name' with the value 'America'. The 'Job Code Name' row is highlighted in green.

Edit	
Job Code ID	1
Job Code Name	America

The job code name will change to America as shown above.


The 'All Job Codes' screen displays a table with four rows. The first row is highlighted in green and shows '1' for Job Code ID and 'America' for the name. The other rows show '2' for UK, '3' for Mexico, and '4' for Canada.

All Job Codes	
1	America
2	UK
3	Mexico
4	Canada

When you select all job codes, America will be displayed in job code ID 1 as shown above.



To delete the job codes in the particular group select **Job Code**.



Select **All Job Codes**




Select **Country** as shown above



Select the job code you wish to delete.


Here select **USA**.



Click on the **Edit** function to change the name of the group.




When you select **Delete** it will delete the particular group you want to delete



When you press **Delete** the above screen will be displayed.

When you press **NO** to execute it will go back to last menu screen and nothing will be edited or deleted



When you press delete the above screen will be displayed.

When you press **YES** to execute it will execute the function and delete the particular job group you selected "Country".




Group name Country is deleted and the other groups remains as shown above.



Job Code Options_Menu_Operation select **Job Code** icon.




Job Code Options_Menu_Operation select **Job Code** icon.



12.3 JOB CODE OPTIONS

Select **Job Code Options**.




Turning **ON** options will enable and **OFF** options will disable the **Job Code Required**. "Input Screen Timeout(s)" is used to set up the time period for displaying the job code list in seconds.

Switch **Job Code Must Defined** to **ON** force a job code to be selected before verification.




When you turn **OFF** the job code required function, it will disable that function.


When you turn **ON** the job code must defined, it will enable the function and it will show as image above.




Select Input Screen Timeout as shown above.




Select the time you want the screen to go idle. In this case 5 seconds is selected. when you select 5 seconds the screen will go to idle state if no registration or activity is performed on the clock.




Select user defined function as shown above to set your own time for input screen timeout.



After selecting user defined function, the screen above will allow you to input the time.



Here we put 15 seconds and then click on confirm **OK** function to get that time selected.




After pressing confirm **OK** function the image will be displayed as above.



Turning **ON** options will enable the **Job Code Required** function
Switch "Job Code Must Defined" to **ON** to force a job code to be selected before verification

The input screen timeout for job code is selected as 15 seconds as shown above.




Turning **ON** options will enable the **Job Code Required** function
Switch **Job Code Must Defined** to **OFF** will not force a job code to be selected before verification



12.4 JOB GROUP OPTION MENU OPERATION

Select **Job code**



Select **Job Group options**.

Pressing **ON** / **OFF** will enable and disable each individual **Job Group**.

The name of the group can be edited using **Set Job Group Name** individually.

To set a Job Group Name click on set job group name as shown above.

This screen will appear when you press the set job group name.

To change the job group name to country as shown above we need to press* key to switch the input method and type country using the keypad.

After that press confirm **OK** button.

After you press confirm **OK** button the set group name will change from undefined 1 to Country as shown above.

Similar way you can put the different job group name as shown above. Group1>> Country, group 2>> State Group3>> City.

Job Group Options

Job Group 1	ON
Set Job Group Name	Country
Job Group 2	OFF
Set Job Group Name	State
Job Group 3	OFF
Set Job Group Name	City

Select the job group you want to enable by pressing the **ON** function. Other groups with **OFF** functions will be disabled. The job code functions will be active only to the groups which are enabled.

Job Group Options

Job Group 1	ON
Set Job Group Name	Country
Job Group 2	ON
Set Job Group Name	State
Job Group 3	ON
Set Job Group Name	City

To change the group name select Set Job Group name.

Job Code Name

Please input

Country

[Aa]

Change the current group name country by pressing* key on the keypad of the clock

Job Code Name

Please input

Nation

[Aa]

Change the group name to Nation as shown above.

Job Group Options

Job Group 1	ON
Set Job Group Name	Nation
Job Group 2	ON
Set Job Group Name	State
Job Group 3	ON
Set Job Group Name	City


The group name will be change to Nation as shown above.



TIP CODE




Select Tip Code and press **OK**.




If you press **ON** it will enable that tip code function.

If you press **OFF** it will disable that tip code function

Here Tip group 1 is enabled and Tip Group 2 and 3 are disabled.




To set the tip group name select **Set Tip Group Name**.




13.1 TIP CODE SETTINGS

Switch **Enable All Tip Group** to **ON** to enable Tip Code function; **OFF** to disable Tip Code function.


The groups can be turned on/off individually using **ON** or **OFF** associated with each tip group




If you press **OFF** under enable all tip group, it will disable all the tip groups and no tip groups will be shown as seen above.




When you select the set tip group name, the following image will be displayed and you can change the name of the group from breakfast to another name by using the keypad on the screen



Here the Tip group is being changed from breakfast to Dinner with the keypad on the clock.



After you change the name press Confirm **OK**




Once you hit the Confirm **OK** button the set tip group name will be changed to Dinner as shown above.



13.2 TIP CODE

Select "Personalize".



Select **Shortcut key mappings** .



Select **F3** as tip code.

F3	
Punch State Value	251
Function	Tip Code
Select Tip Group	Disable

In F3 Select Punch State Value.

Punch State Value
Please input (0 ~ 254)
251
Confirm (OK)
Cancel (ESC)

You can change the punch state value by entering into the input section using the keypad.

F3	
Punch State Value	251
Function	Tip Code
Select Tip Group	Disable

Select **Function**

Function
Firmware Info
Work Code
Public Message
Personal Record Search
Job Code
Tip Code


In function key select **TIP code**.

F3	
Punch State Value	251
Function	Tip Code
Select Tip Group	Disable


Pressing switch will enable and disable the each individual **Job Groups**.

Select Tip Group
<input type="checkbox"/> Breakfast
<input type="checkbox"/> Lunch
<input type="checkbox"/> Supper


If the check mark is not selected on the box no tip group will be selected and it will be disabled as above




If you check mark all the groups as shown above, all the tip groups will be enabled.




If all three tip groups are selected, **Select Tip Group** will be display as **All Group**.




Select F3 key on the main screen as tip code.




You can edit the tip in the amount of dollars by pressing the up and down arrows on the keypad according to group.
Here for breakfast, the tip is set to 8 dollars. Press confirm **OK** when finished.



You can edit the tip in the amount of dollars by pressing the up and down arrows on the keypad according to group.
Here for breakfast, the tip is set to 12 dollars. Press confirm **OK** when finished.



You can edit the tip in the amount of dollars by pressing the up and down arrows on the keypad according to group.
Here for breakfast, the tip is set to 18 dollars. Press confirm **OK** when finished.




Once all the tips are set according to the group, the user from the group can easily punch in and punch out by their fingerprint and the above image will be displayed.



AUTOTEST




Select "Auto test".



14.1 ALL TEST


Select **Test All**.

The terminal automatically tests the LCD, voice, sensor, keyboard and clock, press **OK** to continue and press **ESC** to exit




14.2 TEST LCD


The terminal automatically tests the display effect of the color TFT display by displaying full color, pure white and pure black and checks whether the screen displays properly.




The terminal automatically tests the display effect of the color TFT display by pure black




You can continue the test by touching the screen or exit it by pressing [ESC]




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press **ESC**




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC



Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




14.3 TEST VOICE

Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press **ESC**




14.5 TEST FINGERPRINT SENSOR

The terminal automatically tests whether the fingerprint collector works properly by checking whether the fingerprint images are clear and acceptable. When the user places his/her finger in the fingered guide, the collected fingerprint image is displayed on the screen in real-time. Press **[ESC]** to exit the test




When you select to test the face the above image will be displayed where you can put your face and verify whether the cam is working properly.



14.4 TEST KEYBOARD

The terminal tests whether every key on the keyboard works normally. Press any key on the [Keyboard Test] interface to check whether the pressed key matches the key displayed on screen. The keys are dark-gray before pressed, and turn blue after pressed. Press **[ESC]** to exit the test.




14.6 TEST FACE

Select **Test Face**



Here I took the sample picture to test the camera.




14.7 XS TEST CLOCK RTC


Test Clock RTC: The terminal tests whether its clock works properly by checking the stopwatch of the clock. Touch the screen to start counting, and touch it again to stop to check whether the counting is accurate. Press [ESC] to exit the test.



SYSTEM INFORMATION



Select **System Info**.



15.1 DEVICE CAPACITY


Select "Device Capacity".

Device Capacity	
User (used/max)	1/10000
Admin User	0
Password	1
Fingerprint (used/max)	1/3000
Badge (used/max)	1/10000
ATT Record (used/max)	4/50000

The number of enrolled users, administrators, passwords, the total fingerprint storage capacity and occupied capacity, ID cards and attendance capacity are displayed respectively

Device Capacity	
Admin User	0
Password	1
Fingerprint (used/max)	1/3000
Badge (used/max)	1/10000
ATT Record (used/max)	4/50000
User Photo(used/max)	0/2000

The number of enrolled users, administrators, passwords, the total fingerprint storage capacity and occupied capacity, ID cards and attendance capacity are displayed respectively



15.2 DEVICE INFO




Click on **Device info**.

Device Info	
Device Name	uFace800-ID-WIFI
Serial Number	AF44174260019
MAC Address	00:17:61:12:ab:a2
Fingerprint Algorithm	Finger VX10.0
Face Algorithm	Face VX7.0
Platform Information	ZMM220_TFT

The Device name, serial number, MAC Address, Fingerprint Algorithm, platform information and MCU version are displayed on device interface.

Device Info	
MAC Address	00:17:61:12:92:52
Fingerprint Algorithm	Finger VX10.0
Platform Information	ZMM200_TFT
MCU Version	24
Manufacturer	ZK Tech
Manufacture Date	07/31/2017 01:09:15

Manufacturer and Manufacturer date are displayed on the device interface

System Info	
	Device Capacity
	Device Info
	Firmware Info

15.3 FIRMWARE INFO

Click on **Firmware Info**.

Firmware Info	
Firmware Version	Ver 8.0.3.6-2.12
Bio Service	Ver 2.1.12-20160928
Push Service	Ver 2.0.24S-20170120
Standalone Service	Ver 2.1.0-20160426
Dev Service	Ver 1.0.101-20151031
System Version	Ver 14.12.29-20161214

The Firmware version, Bio Service, Push Service, Standalone Service, Dev Service and System Version are displayed on the firmware info interface

